

Electromechanical Automation Product Release



Bulletin # SR825
Date: Wednesday, August 20, 2008
To: All Master Pricelist Holders, CTC Only, RSMs
Product: ACR Ethernet Driver for InteractX and Interact Xpress
Subject: ACR Ethernet Driver Release

Parker Electromechanical Automation is pleased to announce the release of the ACR Ethernet Driver for InteractX and Interact Xpress

Description and Features

The ACR Ethernet Driver for InteractX and Interact Xpress enables Ethernet communications between Parker HMI and the Aries Controller. This driver is intended to support applications with up to 100 tag references. It is also designed to connect exclusively to the controller via a crossover cable or Ethernet switch and cannot be connected to the controller at the same time as another HMI or configuration software (such as ACRView).

Pricing

No charge for existing owners of InteractX and Xpress.

Availability

The driver is available for download from the HMI support forum at www.ctcusa.com/snitz_forums as well as the Xpress and InteractX product pages on www.parkermotion.com.

Installation Instructions

To install the driver for InteractX:

- 1) Copy the file "acr_ethernet_u.dll" to "[InteractX Installation Folder]\COMM Server\Drivers".
- 2) Copy the file "acr_ethernet.chm" to "[InteractX Installation Folder]\COMM Server\Help".

To install the driver for Xpress:

- 1) Copy the file "acr_ethernet_ce.dll" to "[Xpress Manager Installation Folder]\COMM Server\CE Drivers".
- 2) Copy the file "acr_ethernet_u.dll" to "[Xpress Manager Installation Folder]\COMM Server\Drivers".
- 3) Copy the file "acr_ethernet.chm" to "[Xpress Manager Installation Folder]\COMM Server\Help".

The Xpress driver requires version 1.63 of Interact Xpress.

If you have any questions, please contact:

- Technical Assistance, Applications Engineering Department (e-mail: emn_support_ctc@parker.com or call 513-831-2340)